



**IMPORTANT:** Always dispose and/or recycle used batteries in accordance with the hazardous waste recovery and recycling regulations for your location. Your city, state, or country may also require you to comply with additional handling, recycling, and disposal requirements. **WARNING:** Failure to follow these warnings and instructions can lead to heat generation, rupture, leakage, explosion, fire, or other injury, or damage. Do not insert the battery into the compartment in the wrong direction. Always replace the battery with the same or equivalent type. Never recharge or disassemble the battery. Never place the battery in fire or water. Always keep batteries away from small children if batteries are swallowed, promptly see a doctor.

## GoControl! Security Battery Replacement Guide

### Control Panel

Call 208-623-6331 to order.



### Wireless Door /Window Contact

Requires: one (1) CR123A 3V Lithium battery. Procedure: At the top (a short edge) of the sensor, push down the clip to unlock the sensor's backplate. Then, gently pull down on the backplate to remove it. Place a small flathead screwdriver in the slot between the metal clip and battery. Holding down the raised plastic edge in the battery compartment, gently twist the screwdriver to pop out each battery. Insert the replacement batteries in the compartment. The plus (+) sign of both batteries should be facing up and the minus (-) side facing down.



### In-Frame Wireless Door Contact

Requires: one (1) CR123A 3V Lithium battery. Procedure: Remove the two screws and pull contact from door jamb. Use a small flat-head screw driver to push the clips on the side of the sensor casing in, Then remove the cap. Before removing the circuit board, it is important to observe how the board fits into the grooved channel on the inside of the sensor cap. When replacing the board, ensure the circuit board fits back into the channel for a proper fit. Gently remove the circuit board from the casing. Notice how the battery compartment is built into the end of the circuit board. Remove the battery from the compartment. Insert the new or replacement battery into the compartment. Always match the plus (+) sign on the battery with the flat side of the compartment and the minus (-) sign on the battery with the spring side. Reinsert the circuit board to fit snugly inside casing and then replace the sensor cap, taking care to ensure the circuit board fits properly in the cap's grooved channel. Reinsert contact into door jamb and replace screws, careful not to over tighten.



### In-Frame Wireless Plunger Contact

Requires: one (1) CR1620 3V Lithium battery.

Procedure: Remove the two screws and pull contact from door jamb. Remove rubber cap from rear of contact. Slide old battery out from under the battery clip and replace with a fresh battery. Replace rubber cap. Reinsert contact into door jamb and replace screws, careful not to over tighten.



### Wireless Motion Detector

Requires: one (1) Panasonic CR123A 3V Lithium battery. Procedure: Remove the screw from case bottom. Remove the backplate using a bottom-to-top lifting motion. Remove old battery and insert replacement battery. Always match the plus (+) sign on the battery with the flat side of the compartment and the minus (-) sign on the battery with the spring side. Replace the PIR cover and screw. (If the motion detector is on a bracket, you may remove it from the bracket by lifting straight upwards. Keep the motion detector level as you lift gently so as not to damage bracket).



### 4-Button Keyfob

Requires: one (1) CR2025 3V Lithium battery. Procedure: Remove the screw from the back of the keyfob. Separate the faceplate from its backplate. Slide the existing battery out from under the metal battery clip on the printed circuit board. Insert the new battery into the metal battery clip on the printed circuit board. The plus (+) sign on the battery should be facing up and the minus (-) side facing down. Replace the printed circuit board into the faceplate of the keyfob. Replace the key ring in the space provided bottom of the fob. Then snap the keyfob faceplate and backplate closed. Secure the screw into the back of the keyfob.



### Wireless Doorbell

Requires: one (1) CR2032 3V Lithium battery. Procedure: Insert a small flat head screwdriver at the top of the backplate to remove it. Use the battery pull tab to remove the old battery. Replace battery and snap cover back into place.



### Wireless Smoke/Freeze Detector

Requires: three (3) premium AAA batteries. Procedure: Remove the alarm from its base by twisting the it counter-clockwise. Remove the old batteries. To ensure proper power-down sequence, wait a minimum of 20 seconds before inserting new batteries. Insert three AAA batteries in the battery compartment. Follow the polarity diagram inside the compartment. Reinstall the alarm onto the mounting base by turning the alarm clockwise until the mating marks align. After the power-up sequence, the green LED should blink about once every 12 seconds to indicate normal operation.



### Wireless Glass Break Detector

Requires: two (2) CR123A 3V Lithium batteries. Procedure: Holding the cover and base, twist the cover in a counter-clockwise motion. When the imprinted arrows on the side of the detector are aligned, separate the unit. Remove the old batteries. Insert the batteries in the compartment. Always match the plus (+) sign on the battery with the flat side of the compartment and the minus (-) sign on the battery with the spring side of the compartment. It takes approximately five (5) seconds for the detector to power ON. Holding the cover, align the imprinted arrows on the detector and then twist the cover in a clockwise motion to close the unit.



### Wireless Carbon Monoxide Detector

Requires: one (1) CR123A 3V Lithium battery. Procedure: Remove the detector from its mounting base by twisting the detector counterclockwise. To ensure proper power-down sequence, wait a minimum of 20 seconds before installing new battery. Install a new 3V CR123A lithium battery in the battery compartment. Follow the polarity diagram inside the compartment! Reinstall onto the mounting base by turning the detector clockwise. After the power-up sequence the green LED should blink about once every 12 seconds to indicate normal operation.





***GoControl! Battery Replacement Guide***



***Go to [www.evergreensecurity.net/html/interactive](http://www.evergreensecurity.net/html/interactive) for demo videos and links for Android and iPhone apps.***